



**Handlebar Mounted Mirrors  
KIT P/N 2877222**

**APPLICATION:  
All ATV with 7/8" OD Handlebars**

This kit includes:

Qty	Part Description
1	Left mirror with hardware
1	Right mirror with hardware

**IMPORTANT:** Your Polaris accessory is designed exclusively for your vehicle. Please read the instructions thoroughly before beginning. Installation of any item is easier if the vehicle is clean and free of debris.

**APPROXIMATE INSTALLATION TIME:** 15 minutes

**INSTALLATION INSTRUCTIONS:**

1. Install the band clamp around the handlebars.
2. Place the crush bushing on the inside of the band clamp
3. Insert the mirror stalk through the band clamp and crush bushing.
4. Install and tighten the nylock nut.
5. Repeat process on other side. The band clamp may have to face forwards on one side and rearwards on the other side in order to clear cables/controls.

